KitchenAid® OVEN PARTS

For Models:KEBS278DBL10, KEBS278DWH10, KEBS278DBS10, KEBS278DSS10

(Black) (White) (Black Stainless) (Stainless Steel)

27" BUILT−IN ELECTRIC
DOUBLE OVEN
THERMAL CONVECTION
SELF−CLEAN



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models:KEBS278DBL10, KEBS278DWH10, KEBS278DBS10, KEBS278DSS10
(Black) (White) (Black Stainless) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
2		Trim, Side
	4450850	RH Black & BS Mdls
	4450851	RH White Model
	4452081	RH Stainless Steel
	4450853	LH Black & BS Mdls
	4450854	LH White Model
	4452082	LH Stainless Steel
	4449747	Black & BS Mdls
	4449041	White Model
3		Hinge Receiver
	4455722	Left Hand
	4455723	Right Hand
4	4448520	Bumper, Door
5	4455509	Bracket, Support
6	4452200	Divider, Vent
	4449809	Screw
7	4455285	Top Chassis
	4449809	Screw
9	4452158	Tube, Vent
	4449154	Screw
10	4452163	Lens, Light
11	4448972	Oven Light Assy
12	4452164	Bulb, Light
	4449748	Screw
14	4451739	Frame, Front
	4449040	Screw
	4450118	Nut
15	4455381	Gasket, Door
19	4451477	Support, Insulation
	4449809	Screw
20	4451605	Cap, Spacer
21		Rail, Side
	4450581	Right Side
	4450582	Left Side
	4448444	Grommet
	4449154	Screw
22	4451896	Latch Assy
23	4452224	Solenoid
24	4452312	Microswitch N.C.
	4449154	Screw
25	4454691	Side, Chassis (R.H. & L.H.)
	4449809	Screw
26	4452233	Back, Chassis
	4449809	Screw
27		Liner, Oven (Not serviceable)
28	4451426	Micro Switch
29	4455636	Sensor
	4449154	Screw
30	4451537	Spring, Latch
33		Deflector, Vent
	4450280	Black, White & Black Stainless Models
	4452489	Stainless Steel Model
34	4452266	Vent, Center
37	4452223	Thermostat (TOD)
	4449809	Screw
43	4455529	Base, Chassis
	4449809	Screw
49	4448933	Retainer, Gasket
	4449154	Screw
50	4451747	Cover, Back
	4449809	Screw
51		Trim, Bottom
	4448475	Black & BS Models
	4448476	White Model
	4452480	Stainless Steel Model
	4452152	Bracket, Mounting Bottom Trim
	4159465	Screw
53	4449845	Support, Bracket
	4449809	Screw

FOLLOWING PARTS NOT ILLUSTRATED

INSULATION

4449315	Insulation, Wrap
4450364	Insulation, Back
4452336	Insulation, Bottom Stainless Steel Model

CONTROL PANEL PARTS

For Models:KEBS278DBL10, KEBS278DWH10, KEBS278DBS10, KEBS278DSS10
(Black) (White) (Black Stainless) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1		Control Panel Assy. W/Membrane Switch
	8300380	Black & BS Models
	8300379	White Model
	N/A	Stainless Steel
2	4451033	Gasket, Control Panel
3	4453165	Microcomputer
	3400832	Screw
4	4452376	Membrane Switch Stainless Steel Model
5	4451790	Panel, Control Stainless Steel Model

OVEN DOOR PARTS

For Models:KEBS278DBL10, KEBS278DWH10, KEBS278DBS10, KEBS278DSS10
(Black) (White) (Black Stainless) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1	4451718	Door Liner
2		Hinge, Door
	4455524	Black & White Models
	4455525	Black Stainless & Stainless Steel Models
	4449743	Screw
3	4449253	Glass, Inner
4	4451721	Insulation, Door
5	4451670	Retainer, Glass
	4449809	Screw
7	4449257	Glass, Inner
9	4451668	Retainer, Glass
	4449809	Screw
12		Door Glass, Assy
	4452071	Black Model
	4452072	White Model
	4452077	BS Model
	4452315	Stainless Steel Model
13		Door Handle
	4448411	Black & BS Models
	4448412	White Model
	4452087	Stainless Steel Model
14	4450813	Bracket, Handle Black, White & Black Stainless Models
	4451040	Screw
19	4450361	Shield, Heat
	4449809	Screw
21	4451673	Seal, Door Top
23		Retainer, Clip
	4450863	Black & BS Models
	4450864	White Model
24		Bracket, Handle Stainless Steel Model
	4452487	Right Hand
	4452488	Left Hand
25	4455256	Glass, Inner

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models:KEBS278DBL10, KEBS278DWH10, KEBS278DBS10, KEBS278DSS10
(Black) (White) (Black Stainless) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	4448982	Plug, Button
2	4452156	Element, Broil
	4449154	Screw
3	3147563	Grill, Broiler
4	3147845	Pan, Broiler
5	3181534	Rack, Roasting
6	4448715	Rack, Oven
7	4452155	Element, Bake

Illus. No.	Part No.	DESCRIPTION
8	4448881	Nut, Hex
9	4451583	Fan, Convection
	4449154	Screw
10	4452226	Blade, Fan
11	4448882	Washer, Lock
12	4452227	Nut
13	4451355	Jack, Meat Probe
14	4448948	Probe, Meat
15	4455036	Tray, Bake

Illus. No.	Part No.	DESCRIPTION
17	4450039	Cover, Bake Tray
	4449809	Screw
20	4452157	Element, Convection
	4449154	Screw
21	4448418	Cover, Fan
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models:KEBS278DBL10, KEBS278DWH10, KEBS278DBS10, KEBS278DSS10
(Black) (White) (Black Stainless) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1	4451758	Foam, Block
2	4455178	Elbow, Vent−Top
3		Blower
	6610168	45MM Lower Oven
	4455334	60MM Upper Oven
	4455352	Bracket, Blower 60MM
	4455191	Plate, Service
5	6610122	Transformer, (Lights)
	4449809	Screw
7	4451891	Transformer
	4449809	Screw
8	4451759	Vent, Exhaust
9	4455177	Elbow, Vent−Bottom
10	4451789	Plate, Mounting
11	4449868	Block, Terminal
	3400080	Screw
13		Vent, Control Panel
	4448551	Black, White & Black Stainless Models
	4448548	Stainless Steel Model
	4450038	Screw
14		Side, Control Top
	4451597	Right
	4451598	Left
	4449809	Screw
15	4452244	Back, Control
	4449809	Screw
16	4450550	Cover, Top Rear
	4449809	Screw
17	4448664	Clamp
	4449809	Screw
	112432	Nut
18	4452366	Cover, Top Front
	4449809	Screw
	4452260	Spacer, Foam
19	4451985	Suppressor

OPTIONAL PARTS

For Models:KEBS278DBL10, KEBS278DWH10, KEBS278DBS10, KEBS278DSS10
(Black) (White) (Black Stainless) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION

PAINT, TOUCH−UP (1/2oz.)

72017	White
261869	Cord Brown
72032	Black

PAINT, SPRAY

350930	White
261900	Citrine White
830864	Black

ADHESIVE

591014	Adhesive Loctite (1/3 oz.)
482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION

SPLICING WIRES−−25FT. LENGTH

242828	Wire (12 Ga. 150 c Black)
242820	Wire (14 Ga. 150 c Black)
242821	Wire (14 Ga. 150 c Blue)
242822	Wire (14 Ga. 150 c Brown)
242830	Wire (14 Ga. 200 c Brown)
242823	Wire (14 Ga. 150 c Green)
242824	Wire (14 Ga. 150 c Orange)
242829	Wire (12 Ga. 150 c Red)
242825	Wire (14 Ga. 150 c Red)
242831	Wire (14 Ga. 200 c Red)
242826	Wire (14 Ga. 150 c White)
242827	Wire (14 Ga. 150 c Yellow)
242832	Wire (14 Ga. 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION

WIRING HARNESS PARTS

4451926	Harness, Wire (Latch)
4455727	Harness, Wire (Main)
4450953	Conduit, Double
4450800	Screw
4448664	Clamp
4449809	Screw
112432	Nut
4452222	Spacer, Harness
4454835	Tie, Cable
4451761	Support, Wiring
4454842	Tie, Cable
313438	Harness, Clip

Miscellaneous

814381	Hinge Pin Kit
4448950	Screw, Install (4)